

Email: info@trellisdirect.co.uk Telephone: 08454 96 96 49

Trellis & Fencing Installation Guide



For Square Trellis, Garden Screening, Diamond Trellis, Solid-Boarded Panels.

There are recommendations, they may vary according to the site conditions:

- Foundation Pit: Min depth 450mm / 500mm x 400mm x 400mm
- Set top of DPC [supplied] to be min 20mm above the finished ground height
- Posts set on a gravel base
- We recommend Post Crete mix to form the foundation concrete around posts

Note;

Size of foundation will vary according to ground condition, sizes assume good clay.

Also account must be taken of the exposure to the elements against trellis.

Trellis to be set min 50mm above the finished ground level.

Maintenance

At least once a year check the condition of the posts and trellis paintwork, touch up with the paint provided.