



Setting-out Instructions

1. Excavate soil to receive post. We recommend 500mm depth.
2. At ground level fix DPC (supplied) around post, ideally 25mm above ground level, 200mm below ground level.
3. Using props to support posts, fill pit using postcrete or similar, breaking line of DPC by approximately 50mm.
4. Back-fill with earth to ground level.

Fixings

5 x 50mm screws supplied for fixing boarding panels to posts.
 5 x 70mm screws supplied for fixing post caps to posts.